








Skipper 5000 Spare Parts & Accessories



Item	Order.No	Description	Picture
1	30220275	SP, Feet, Set(4) A51 A71 S51 S71	
2	30257139	SP, PCBA, Keyboard Adapter, S51 S71	
3	30257230	SP, Switch Power, 18V,65W, S51 S71	
5	30257232	SP, PCBA, Mainboard, S51	
6	30257153	SP, PCBA, A/D Board, S51 S71	
7	30257154	SP, Rubber Pad, RA S51 S71	

8	30257155	SP, Printer, LTPD245B, S51 S71	
9	30217470	SP, Rubber Roller, LTPD245B, S51 S71	
10	30090611	SP. Keyboard, S51	
11	30217313	SP, Harness kit, S51	
12	30220274	SP, Cover, battery, S51	
14	30264890	SP, Display, orange, S51	

15	30211290	Battery Kit, Lead Acid, S51	
16	30257157	Tower, S51	
18 NS	30235164	Ext.12~24V connector kit, S51 S71	
17	30325506	SP, PCBA, backup battery, S51 S71	
18	30326679	mounting plastic part kits, rear display,S51	